

Technical Manual



**01.021.01**

**REMOVE AND INSTALL CARBON  
FIBER SPOILER ASSEMBLY**

**STARK FUTURE**



## SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



## TOOLS

TRX 30



## OPERATION TIME

10 Minutes

# REMOVAL



## WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Remove the spoiler assembly. Refer to:



01.007.01

[Remove and Install spoiler assembly ↗](#).

- 2 Unscrew carbon fiber spoiler assembly bolts, 3x on each side.



## NOTE

Take caution not to lose any black spacers when removing the bolts.

- 3 Grab the carbon fiber spoiler assembly from the sides and pull backward and upward.

# INSTALLATION



## WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.



## NOTE

Check that the carbon fiber spoiler assembly fittings on the bike are clear of wirings or debris.

- 1 Slide the carbon fiber spoiler assembly forward and downward.



## NOTE

Ensure to insert the black spacers with the bolts.

- 2 Tighten the carbon fiber spoiler assembly bolts to **8 Nm**.
- 3 Install the spoiler assembly wiring screw to **3 Nm**.

## 4

4 Install the spoiler assembly. Refer to:



01.007.01

[Remove and Install spoiler assembly ↗.](#)

**5**

01.021.01

Remove and install carbon fiber spoiler assembly

starkfuture.com

ENG 2023-06

Copyright © 2023 Stark Future SL. All rights reserved.  
Reproduction, even in part, as well as copying of all kinds,  
is permitted only with the express written permission  
of the copyright owner.

**STARK FUTURE**