Technical Manual

02.009.01

REMOVE AND INSTALL
HAND BREAK MASTER CYLINDER

STARK FUTURE



SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



TOOLS

HEX 8



OPERATION TIME

5 Minutes

REMOVAL



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Hold the master cylinder and unscrew bolts.
- 2 Remove master cylinder clamp.



NOTE

Beware of falling objects

INSTALLATION



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Hold the master cylinder in place.
- 2 Install clamp.
- 3 Tighten the bolts by hand.



NOTE

Before the final tightening, place the brake lever in the prefered position.



WARNING

Ensure the brake lever can move freely and you are able to fully press it without rubbing or touching other handlebar controls.

4 Tighten the bolts to 3 Nm.



WARNING

Check brakes operation before operating the bike.

starkfuture.com

ENG 2023-06

Copyright © 2023 Stark Future SL. All rights reserved.

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.

STARK FUTURE