Technical Manual

06.030.07

DISCONNECT AND RECONNECT HANDLEBAR CONTROLS

STARK FUTURE



SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



TOOLS

TRX 30



OPERATION TIME

15 Minutes

REMOVAL



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

1 Remove the front number plate. Refer to:



01.006.01

Remove and install fron number plate 7.

- 2 Untighten the front connectors lid bolts.
- 3 Remove the connectors box lid.
- 4 Disconnect the throttle, wireless charger module and control switch sockets.



INSTALLATION



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Connect the throttle, wireless charger module and control switch sockets.
- 2 Gently press the plugs onto the respective front connectors box slots.
- 3 Clip the lid onto the front connectors box.
- 4 Tighten the front connectors box bolts to **5 Nm**.
- 5 Install the front number plate. Refer to:



01.006.01

Remove and install fron number plate 7.



WARNING

Turn ON the bike and connect to the Stark phone to check battery status and that the bike is operating normally after disconnecting electronic components.

starkfuture.com

ENG 2023-08

Copyright © 2023 Stark Future SL. All rights reserved.

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.

STARK FUTURE